
CV Vol 1
CV Vol 2
CV Vol 3
CV Vol 4
MPC_2
MPC_3
LED Pan R K4
LED Pan R A4
LED Pan L K4
LED Pan L A4
LED Pan R K3
LED Pan R A3
LED Pan L K3
LED Pan L A3
LED Pan L A1
LED Pan L K1
LED Pan R A1
LED Pan R K1
LED Pan L A2
LED Pan L K2
LED Pan R A2
LED Pan R K2
NC
CV Vol Man 4
CV Vol Man 3
CV Vol Man 2
CV Vol Man 1
+5V
MPC_1
Iabc Vol 4
Iabc Vol 3
Iabc Vol 2
Iabc Vol 1
LED Vol A1
LED Vol K1
LED Vol A2
LED Vol K2
LED Vol A3
LED Vol K3
LED Vol A4
LED Vol K4
MPC_4
-12V
GND
+12V
MPC_16
OUT R/L
OUT R
OUT L
Scan CV
Scan Man
Spread CV
Spread Man
MPC_7
MPC_12
MPC_14
IN 4
IN 3
IN 2
IN 1
C1 L
C1 R
C2 L
C2 R
C3 L
C3 R
C4 L
C4 R
CV Pan
CV Pan
CV Pan
CV Pan
CV Pan
CV Pan
CV Pan
CV Pan
www.haraldswerk.de
Pand and Scan
V 1.0.1-B / 2022_04